


Setting a Password on RIM BlackBerry Devices using Handheld Software Version 5.0

IMPORTANT: The device will automatically perform a master reset if the password is incorrectly entered 10 times.

Enable password security lock

1. Press the [Menu key](#), then scroll to and select the Setup icon  (to select, press the trackpad in).
2. Scroll to and select the Options icon .
3. Scroll to and select **Password**.



4. Scroll to and select the "Password" field.



5. Scroll to and select **Enable**.


NOTE: If this device is registered on a BlackBerry Enterprise Server (BES Express), the IT/BES Administrator may have pushed an IT Policy to the handheld to automatically enable the Password Security Lock. If this is the case, there will not be an option to enable/disable the Password Security Lock.



6. Press the [Menu key](#), then select **Save**.



7. Enter the requested password, then press the trackpad in:
 - Enter the desired "New Password".




- Re-enter the new password for verification, and then press the trackpad.



Change the password


1. Press the [Menu key](#), then scroll to and select the Setup icon  (to select, press the trackpad).
2. Scroll to and select the Options icon .
3. Scroll to and select **Password**.




4. Scroll to and select **Change Password**.




5. Enter the current password, then press the trackpad.



6. Enter the desired "New Password", and then press the trackpad.



7. Re-enter the new password for verification, and then press the trackpad.



8. Press the [Menu key](#), then select **Save**.

