

## Presence on VOIP phones

Icon	Description
	Presence icon signifying this contact is available; the contact whose presence is indicated is registered (logged in) and that phone is in an idle state.
	Presence icon signifying this contact is currently on his or her phone; Busy indicator.
	Presence icon indicating this contact is not logged in (unregistered).
	Presence icon indicating this contact's phone is busy with the Send All Calls feature active. This icon also designates that a feature is not available at this point of a call.
	Presence icon indicating the screen saver on this contact's phone is on, or the phone is locked.
	"No Presence Available" icon indicating that although you set up presence tracking for this contact, telephone server differences prevent this contact from being tracked.
	Presence icon indicating this contact is in a conference call.

If you go on your phone to Options and Setting then go down to MY PRESENCE...., and it will show the below....

